

FAT SHARK

RC VISION SYSTEMS

DOMINATOR SE
MODEL FSV1065

USER MANUAL



Revision A 09/26/2016

For more product information, please visit:
www.fatshark.com
All Rights Reserved

Contents

Product Contents.....	3
Controls Diagram	4
Headset Operation	5
Controls	5
DVR Operation	5
AV Cable Pinout	6
Powering Options	6
ezUHF TX/JR Module.....	6
Futaba Radio.....	6
Base Station	6
1000mA Battery Pack.....	6
Battery Charging	7
Accessories	8
Trinity Head Tracker.....	8
Receiver Modules (1.3G/2.4G/5.8G)	8
Diopter Lens	8
Specifications	9
Operational Advice	10
Trouble Shooting.....	11
Warranty.....	11

Introduction

Congratulations on purchasing Fat Shark Dominator SE modular VGA FPV video goggle with analog recording DVR. To ensure your continued enjoyment, please take the time to read through this operating manual thoroughly before using.

Product Compatibility

The Dominator SE has been designed to adhere to established video standards and is compatible with any product also adhering to accepted video standards. Due to the high number of different manufacturers and variation in quality, it's impossible for us to have tested with every product combination and some troubleshooting may be required if mix/matching components. The Dominator SE has been thoroughly tested with ImmersionRC gear. For best results and no compatibility issues, Fat Shark recommends ImmersionRC gear for your accessory products.

Fat Shark only guarantees video compatibility with NexwaveRF brand modules.

IMPORTANT!!!! Product Warning!!!!

DO NOT LEAVE HEADSET EXPOSED TO DIRECT SUNLIGHT. SUNLIGHT WILL MAGNIFY THROUGH THE OPTICS AND BURN HOLES IN THE LCD COLOR FILTER (appears as white open areas).

THIS WILL NOT BE COVERED BY WARRANTY. KEEP GOGGLES IN PROTECTIVE CASE WHEN NOT IN USE

Product Contents

Carry Case



Dominator SE Headset w/ Orange Faceplate



7.4V, 1000mAh Li-po Battery w/ LED Indicator



Battery Discharge Adapter



5G8 Receiver Module (32ch with RaceBand)




SpiroNET Circular Polarized Antenna



Quick Start Manual



Controls Diagram



Headset Operation

Controls

Brightness/contrast control: pressing left and right increases/decreases display contrast. Press forward/back increases/decreases brightness.

Channel select: Pressing channel up/down buttons will cause the channel to incrementally increase/decrease from channels 1 to 8 (see relevant receiver module for channel map). Audio beep on channel change. A long beep sounds on channel top and bottom limits.

Low battery warning: Audio warning if input voltage drops below 6.8V

Volume control: each press of button increments volume up or down.

Head tracker: (refer to documentation included with module purchase)

RX power switch: The RX module power is independently controlled via this switch. If a module is inserted, but desired video source is via the AV cable; the RX module needs to be turned off to avoid image conflict.

DVR control: Connect AV cable to AV out port on right side of headset. Connect recording device to cables and set up as per manufacturer directions.

DVR Operation

Note:

1. SD card **MUST** be formatted before use to ensure stable recording.
2. DVR is for analog recording only, no HD recording.
3. Do not place alternative files that you want to keep into the DVR. The DVR may not recognize the file space and write over your files. Use dedicated SD card.

Recording:

After powering goggles, turn on DVR by depressing vertically and holding the DVR control button for 1 full second (**long press**).

RED LED should now show solid.

Ensure SD card is inserted and **short press** to start recording (RED LED will slowly FLASH (~2 times/second)).

Short press again stops recording (turns to solid RED LED).

Playback

Note: requires turning off external receiver and removing any other AVin sources (to not conflict with menu navigation OSD).

After turning on DVR and in stop record mode (SOLID RED LED) depress and hold DVR button for 1 second (**long press**) to enter menu.

Menu Navigation

Playback (press right to enter)

Now can see: Preview shot with file number

press **up/down** to change file number

Press **right** to play

Up/down controls playback speed/direction

Right press pause/play

Left press, back to main menu

Format (press right to enter)

Execute (press right)

Pressing **left** from main menu exits menu

AV Cable Pinout

3.5mm AV Connector: Yellow: Video,
White: Audio Left, Red: Audio Right



Powering Options

If multiple power sources are supplied at same time (i.e. Futaba radio and head strap battery) the headset will draw power from the highest voltage.

ezUHF TX/JR Module

ImmersionRC's ezUHF transmitter and JR transmitter module can supply power (and head tracking control) to the Dominator SE goggle via a mindIN cable (included with the ezUHF).

Futaba Radio

The Dominator SE can be powered off a Futaba radio via the Data Cable.

Note: Best to upgrade the Futaba radio to a 3S 2200mAh radio lipo pack for this type of connection as the headset will cause extra drain on the transmitter battery pack. A normal NiMH radio battery will not have sufficient battery life for safe flying.

Base Station

Use the AV cable to connect the video/audio output of external receiver.

We do not recommend powering the goggles off RC packs without our Safety Shield (see accessories) as RC packs have no current limiting circuitry to prevent fires caused from shorts.

1000mA Battery Pack

The latest Fat Shark 1000mAh pack with a row of stylish blue LED indicators allows you to visually check its remaining capacity (4 levels) to prevent a sudden power/vision lost. It seats securely in the headset strap pocket. The soft silicone battery cable extends out of the top of the pack to avoid contact with head strap.

Barrel connector cable features high strand count wire for flexibility and long life. Wire stress is minimized by the additional rubber gasket around the cable exit. Balancing circuit is already built inside, for charging, only need to connect the barrel connector via the supplied adapter cable to RC charger.

Note: this battery can still be charged via the barrel connector with the original Fat Shark headset battery charger.




Battery Charging

This lithium polymer battery pack is equipped with an internal cell balancing circuit that allows the battery to be charged from standard RC battery chargers. Charge the battery by connecting the barrel connector via the supplied adapter cable and setting the charger for 7.4V, 1000mAh Li-Po, 1A (1C). Some RC chargers require a balance lead connector to be connected to the charger, or else the charging attempt will result in an error. **The balance lead on the battery is not a true balance lead and is only used for powering the optional fan faceplate.** To charge this battery set your LiPo charger to Fast Charge mode, which usually disables the balance lead requirement (set at 7.4V – 2cell - maximum 1A).

On some LiPo chargers none of the above procedures will work. In that case please contact support for alternate charging options at: support@fatshark.com

Note: If battery becomes fully discharged or shorted, an internal safety circuit will trip. To reset the battery, tap 9V direct to the barrel connector via the discharge adapter cable's banana connector. This will instantly reset the battery and it can be recharged as normal.

Connection to Standard RC Chargers



General Lithium Polymer safety and handling instructions:

- NEVER balance charge this LiPo battery.
- NEVER leave a LiPo battery unattended while being charged or discharged.
- ALWAYS monitor the battery and charger during the entire charging process.
- ALWAYS charge LiPo batteries in a fireproof location.
- ALWAYS have a lithium approved "class D type" fire extinguisher available.
- NEVER charge LiPo batteries at currents greater than the "1C" rating of the battery ("C" equals the rated capacity of the battery).
- NEVER continue to charge LiPo batteries if the charger fails to recognize full charge. Overheating or swelling of the LiPo cells is an indication of a problem and the battery should be disconnected from the charger immediately and placed in a fireproof location
- ALWAYS discontinue charging or discharging a LiPo immediately if at any time you see smoke or the battery starting to swell up and leave it in a safe fireproof location for approximately 30 minutes.

Accessories

Trinity Head Tracker



Head Tracker Instalation

Refer to head tracker module manual for up to date and detailed menu setup instructions. For individual radio setup instructions please visit our head tracking support forum at www.FPVlab.com Forum: Sponsors Gate/Fat Shark/Head tracker radio support.

Receiver Modules (1.3G/2.4G/5.8G)



Remove door panel
Remove hole plug

Insert RX module
Align pins to connector

Snap door panel back into place
Door panel will hold Rx module snug.

Refer to module manuals for frequency chart.

Note: Dominator SE only guarantees compatibility with NexwaveRF/RaceBand modules (Fat Shark/ImmersionRC)

Diopter Lens

For near sighted users, diopter lens insert sets are available that include -2, -4 and -6 dpt. Peel off rubber eye cups and insert into slots seated in front of the lens. Replace rubber..

Specifications

Optics:

FOV (field of view): 50 degrees diagonal
Interpupillary Distance (IPD): 59 to 69 mm (adjustable)
Optional Diopter Lens Inserts: -2, -4, -6 dpt

Display:

640*480 VGA 0.44"
NTCS/PAL auto selecting

Audio:

Stereo

User Controls:

Channel Selection
Volume Control
Mode Selection (Wired/Wireless)
Display Control
DVR Control
HT Control

Electrical:

Power Supply: 7 - 13 V (2S/3S supply – fan plate only accepts 2S input)
Power Consumption: 440mA wireless/ 250mA direct mode (no RX)
(@7.4V nominal)
RF Modules (Optional): Infinite channel support on multiple bands
Head Tracker (Optional): Modular (sold separately)
Analog DVR: Micro SD support to 32Gb
Record Rate: 6Mbps (MJPG compression, 30 fps, AVI)
File playback (native recording, no codec support)
Upgradeable via SD card

Battery:

7.4V, 1000A (7.4 Wh) with LED indicator

Interface:

3.5mm AV in/out port
Power in port
3.5mm 3p earphone port
MiniDIN4 data port (head tracking)
Micro SD
RF module port

Mechanical:

Ergonomic molded headset w/ adjustable headband
Dimensions: 169.2 x 80 x 45.5 mm
Weight: 200g

Package:

820g, 20.8 x 14.5 x 11cm

Operational Advice

- **For best performance**, select a channel that has the least amount of interference. While the transmitter is turned OFF, turn on the video headset and look at the screen as you check each channel. Clear channels will have a consistent static background. Channels with interference will have horizontal static lines.
- **Always perform a range test before flying.** This includes AV and RC controls. Some RC receivers can be affected by the proximity of other electronic devices particularly the AV TX.
- Try to space out your components as much as possible to avoid interference to your RC control range (keep stuff away from RX)
- Do not use 2.4Ghz AV with 2.4Ghz RC controllers.
- Your 2.4Ghz TX will not affect the RC control of other RC users (however, their controllers will affect your AV reception).
- Be aware of other 2.4Ghz RC users. If they turn their RC radio nearby, they may knock out your image.
- Until experienced, practice flying in a familiar area to avoid becoming disorientated.
- Due to antenna characteristics, there is a “null” in line with antenna direction. You may experience excessive video breakup when flying overhead
- 5.8Ghz signal strength drops off very fast (2.4Ghz is more gradual). If using 5.8Ghz, stay safely within solid AV range.
- **For maximum distance** it is very important that a clear line of sight exists between the transmitter and the video headset. 2 of the worst causes of interference are human bodies and reinforced concrete.
- Place your TX antenna in open area in a vertical orientation
- **Multipathing** (reflections off buildings/ tall objects) causes signal cancellation and result in broken video. Fly in open areas away from buildings or other tall structures (i.e. barns, hills).
- The headset may become warm to touch during use particularly in the top center region. This is normal. If you are unsure, run the headset for 30 minutes fully powered before flying to ensure normal operation.
- Although you don't require any license to operate this device, you are still legally responsible for operating in a responsible manner.

Trouble Shooting

Observation	Possible Cause/Solution
No image, display is completely dark	- No power supplied. Check power connections.
No image, display is glowing dark grey	- If using wireless module, turn on RX power on bottom of headset. - If using AV in cable, check video source. - Ensure TX is on and camera connections solid
Lots of interference lines (horizontal lines) with 2.4Ghz receiver	- Choose a cleaner channel. - Change to 5.8Ghz AV - Check correct frequency antenna is used
Poor image, dark or not enough contrast	- Adjust display with contrast/brightness button
Lots of interference lines (horizontal lines) when using 5.8Ghz receiver	Check to see if cause is harmonic interference from 2.4Ghz RC controller (turn radio on/off). - Use CH1 on TX/headset (Ch1 not affected by 2.4Ghz) - check correct frequency antenna is used
Head tracker not working (no response or beeping)	- Ensure module pins are aligned correctly into headset socket
Short range	- Ensure correct antenna are installed - Check for other sources of interference - Ensure transmitter has clear LOS to headset. Test in wide open area, away from any obstructions
White dots on LCD display	You were careless and left goggles exposed to sun. Sun burnt off LCD color filter.
Lens fogs up	Cooler optical lens are heated by your humid face causing condensation. -Pre warm goggles by wearing on head or storing in warm location - Power anti-fog mini fan on faceplate from headset battery, each time press the button can run 10min long.
Head tracker does not work (can enter menu)	- Radio doesn't support selective trainer function - Settings incorrect - Trainer switch on RC controller not activated - In Pause mode
Head tracker drifts or has excessive error correction (jumpy)	- Operating inside so compass sensor not correct (use outside) - RC radio interfering with compass sensor (keep RC controller antenna away from headset - Standing near large metal object (such as a car)

Warranty

The system can be exchanged for a new unit within 7 days for any manufacturing defects if returned in new condition. The video headset will be warranted for repair for 2 years if no signs of excessive use. Buyer will be responsible for shipping costs. If beyond the warranty period we will provide repair services.